Camera Settings

HootBooth Classic camera setup

1. Set the Camera to P for most photo applications


LOCK
MENU
INFO.
Image quality
S1
Beep
Enable
Drive/self-tmr
Release shutter without card
ON
Image review
2 sec.
Lens aberration correction
Red-eye reduc.
Disable
Canon


LOCK
MENU
INFO.
Image quality
Beep
Drive/self-tmr
Release shutter without card
Image review
Lens aberration correction
Red-eye reduc.
Enable
2 sec.
Disable
ON
Canon

Expo.comp./AEB
Flash control
ISO Auto
Max.:6400
Auto Lighting Optimizer
White balance
AWB
Custom White Balance
WB Shift/Bkt.
0,0/±0
Canon

Color space sRGB
Picture Style Auto
AF operation ONE SHOT AF
Metering mode
Dust Delete Data
Long exp. noise reduction OFF
High ISO speed NR


Live View shoot. Enable
AF method +Tracking
Continuous AF Disable
Touch Shutter Disable
Grid display Off
Aspect ratio 3:2
Metering timer 16 sec.

Cropping
Histogram disp Brightness
Image jump w/
10
Slide show
Rating
Ctrl over HDMI Disable

Select folder
File numbering Continuous
Auto rotate On
Format card

Auto power off Disable
LCD brightness
LCD auto off Enable
Date/Time/Zone 01/01/'00 00:03
Language English
Video system NTSC

Screen color 1
Feature guide Enable
Touch control Standard
Switch /✳button Disable
Sensor cleaning
GPS device settings

Certification Logo Display
Custom Functions(C.Fn)
Copyright information
Clear settings
firmware ver.: 1.0.0

Set the camera to MF (Manual Focus)